


# User Guide - Large Conference Room

## *Splash Page*

This page is displayed when the system is not in use.

Press anywhere on the screen to begin using the audiovisual system.

Yale University



# User Guide - Large Conference Room

## Operation Page – No Source Selected

This is the main page used to operate the system.

- Source buttons are located on the left.
- Audio controls are on the right.
- The bottom buttons will launch additional controls.

The screenshot shows the Yale University conference room control interface. At the top left, the text "Yale University" is displayed. The main area contains the instruction "Select a source using the buttons on the left...". On the left side, there are two source selection buttons: "Wall Plate" (with a microphone icon) and "Wireless Display" (with a wireless signal icon). On the right side, there are audio controls: a "Source Volume" slider, an up arrow button, a down arrow button, and a "Mute" button (with a speaker icon and an 'x'). At the bottom left, there are two buttons: "Projector" (with a projector icon) and "Camera" (with a camera icon). At the bottom right, the date and time "March 15 2019 9:06 AM" are shown. A power button icon is located in the top right corner. Five yellow callout boxes provide instructions: one points to the source buttons, one points to the power button, one points to the Projector button, and one points to the Camera button.

Select a source to view on the projector

Press to turn the system off

Press to view the projector control page

Press to view the camera control page

# User Guide - Large Conference Room

## Operation Page – Source Selected


This is the main page used to operate the system

- Source buttons are located on the left
- Audio controls are on the right
- The bottom buttons will launch additional controls

Shows information about the currently selected source

Select a source to view on the projector.

The white box indicates the currently selected source.



Use this to adjust the volume level of the selected source

# User Guide - Large Conference Room


## Projector Control

This is the page contains controls related to the video projector

Turn the projector on or off using these buttons.  
The projector will also turn on automatically when a source is selected, and off when the system is shut down.

Press to toggle image mute on or off.  
When image mute is active, nothing will be displayed on the projection screen.

Press to exit the projector control page




Manually raise or lower the projection screen

# User Guide - Large Conference Room

## Camera Control

This is the page contains controls related to the camera

Select a preset camera position.  
Press and hold for 3 seconds to store a new preset.



Press to exit the camera control page


Manually adjust the camera position

# User Guide - Large Conference Room

## *System Off*

This page is displayed when the power button is pressed on the operation page.

Yale University



Press 'Yes' to turn off the system.  
Press 'No' to return to normal operation.