User Guide – Button Panels

Use this button panel to control the associated flat panel display.

Select a source to view on the display.

Selecting a source will also turn on the display.

WALL PLATE

WIRELESS DISPLAY

Press to power off the display

Turn knob to adjust volume up or down

Press to toggle the audio mute on or off

CRESTRON

MPC3-302

Yale University

HB Powering ideas.